





User Manual

SAMSUNG 60 mm F2.8 Macro ED OIS SSA

ENG / KOR / FRE / GER / SPA / T.CHI / ITA / POR / RUS / TUR / S.CHI

This User Manual has been specially designed to guide you through the basic functions and features of your device. Please read the User Manual carefully to ensure safe and correct use.



Please refer to the warranty that came with your product or visit our website www.samsung.com for after-sales service or inquiries.



English

Before Using This Device

Thank you for purchasing the Samsung Lens. The illustrations used in this manual may differ from the actual items. Some functions described in this manual may not be available depending on the camera model. Update the firmware of the camera body and lens. Visit www.samsung.com to download the firmware.

Unpacking

Lens, Lens cap, Lens mount cover, Hood, Case, User manual
• Filter

Mount Type

Samsung NX mount (Exclusive to NX series)

Layouts (See Illustration A)

① Lens mount index ② I-function ring ③ Focus ring

④ Lens hood mount index ⑤ Lens ⑥ FULL/LIMIT switch

⑦ I-function button ⑧ Lens information contacts

Attaching and Removing the Lens

► To attach the lens.
1 Remove the lens cap, lens mount cover, and body cap.
2 Align the red mark on the lens with the red mark on the camera body. Then, rotate the lens as shown in the illustration until it locks into place. (See illustration B)

► To remove the lens, press and hold the lens release button, and then rotate the lens as shown in the illustration. (See illustration C)

► Specifications may change without notice for better performance.

Setting the Focus Distance (See illustration D)

Set the focus distance by using the FULL/LIMIT switch on the lens.

• **FULL:** Automatically set the focus distance (7.3 in (18.7 cm)-infinity)

• **LIMIT:** Focus on a subject that is 15.7 in (40 cm)-infinity from the camera.

Use the Distance Scale function on the camera to display the distance between a subject on the camera's screen. Refer to your camera manual for more details.

► **Camera body:** Camera body (I-Function) to camera body (I-Function) distance

► **Lens:** Camera body (I-Function) to lens (I-Function) distance

► **Operating temperature:** 0~40 °C

► **Operating humidity:** 5~85 %

► **Specifications** may change without notice for better performance.

Health and Safety Information

Please read the following safety tips carefully for proper and safe use.

► **Warning:** Do not stare at the sun through the lens or camera. This may cause severe damage to your eyes.

► **Caution:** Keep your lens or camera away from small children and pets.

► **Setting the Focus Method**

Set the focus method on the camera.

► **Using the full-time manual focus:** If you set auto focus (AF) on the camera, you can adjust the focus more precisely by using both auto focus (AF) and manual focus (MF).

► **Do not apply excessive force to the front of the lens while the camera is in auto focus (AF). Doing so may cause the lens to malfunction.**

Lens Storage and Maintenance

• Store the lens in dry and well-ventilated areas.

• Do not store the lens in areas of high temperature or humidity or in a closet, a car, or confined area where chemicals are stored.

• The lens is not waterproof. Be careful not to allow it to get wet.

• Use only sturdy tripods. Lightweight or unstable tripods may fall over and damage the camera.

Using I-Function

When you press the I-Function button on the lens, you can use the I-Function button on the camera body to change the settings.

In the I-Effect mode, you can select scenes or filter effects that your camera supports. The I-Function ring allows you to zoom in on a subject with less degradation of photo quality than the Digital zoom. This feature is available only when your camera supports I-Scene mode.

► **Using I-Function:** If you set auto focus (AF) and manual focus (MF) on the camera, you can adjust the focus more precisely by using both auto focus (AF) and manual focus (MF).

► **Do not apply excessive force to the front of the lens while the camera is in auto focus (AF). Doing so may cause the lens to malfunction.**

Conservation et maintenance de l'objectif

• Stockez l'objectif dans des endroits secs et bien ventilés.

• Ne rangez pas l'objectif dans des endroits où la température ou l'humidité est extrêmement élevée, et dans un placard, dans un châssis ou dans toute autre zone confinée où des produits chimiques sont stockés.

• L'objectif n'est pas étanche. Veillez à ne pas le mouiller lorsque vous utilisez près d'une source d'eau.

• Ne laissez pas de produits chimiques tels que du diluant, de l'alcool ou du benzène pour nettoyer l'objectif.

• Ne laissez pas tomber l'objectif et ne le soumettez pas à des chocs excessifs. L'objectif est un produit optique précis.

• Évitez d'utiliser l'objectif en cas de changement climatique soudain.

• Utilisez l'objectif dans un sac à plastique ou un étui d'appareil photo pour protéger les particules et protéger la lentille des scratches.

• Ne do not put the camera mounted on a tripod without the lens cap. The inside of the camera can be damaged by direct sunlight.

• Check the lens once every year or for best performance.

• Do not apply excessive force to the front of the lens.

• For safe use of the lens, mount or dismount the lens while the camera is turned off.

• The lens is not waterproof. Be careful not to allow it to get wet.

• Use only sturdy tripods. Lightweight or unstable tripods may fall over and damage the camera.

Using a Lens Hood (See illustration E)

To prevent deterioration of image quality by blocking out unnecessary light, use a lens hood.

► **When you use a flash in situations where the distance between the subject and the camera is close, the flash light may be partially blocked by the lens or a lens hood. To ensure proper lighting, remove the lens hood or adjust the distance between the camera and subjects.**

Using a Filter (optional) (See illustration F)

Before putting a filter on the lens, make sure it is compatible.


► **Refer to "Specifications" for compatible filter size.**

• A filter is a precise optical product. Keep away from dust, dirt or scratches. Also, do not try to mount two or more filters at the same time. Doing so may deteriorate the image quality and cause vignetting (a reduction of an image's brightness or saturation at the periphery as the viewing angle of the lens is hidden).

• In case of a thick frame filter, the vignetting can occur with a wide-angle lens.

► **PlanetFirst represents Samsung Electronics' commitment to the sustainable development and social responsibility through eco-driven business and management activities.**

Please refer to the warranty that came with your product or visit our website www.samsung.com for after-sales service or inquiries.



Specifications

Before Using This Device

Thank you for purchasing the Samsung Lens. The illustrations used in this manual may differ from the actual items. Some functions described in this manual may not be available depending on the camera model. Update the firmware of the camera body and lens. Visit www.samsung.com to download the firmware.

Unpacking

Lens, Lens cap, Lens mount cover, Hood, Case, User manual
• Filter

Mount Type

Samsung NX mount (Exclusive to NX series)

Layouts (See Illustration A)

① Lens mount index ② I-function ring ③ Focus ring

④ Lens hood mount index ⑤ Lens ⑥ FULL/LIMIT switch

⑦ I-function button ⑧ Lens information contacts

Attaching and Removing the Lens

► To attach the lens.
1 Remove the lens cap, lens mount cover, and body cap.
2 Align the red mark on the lens with the red mark on the camera body. Then, rotate the lens as shown in the illustration until it locks into place. (See illustration B)

► To remove the lens, press and hold the lens release button, and then rotate the lens as shown in the illustration. (See illustration C)

► **Specifications** may change without notice for better performance.

Setting the Focus Distance (See illustration D)

Set the focus distance by using the FULL/LIMIT switch on the lens.

• **FULL:** Automatically set the focus distance (7.3 in (18.7 cm)-infinity)

• **LIMIT:** Focus on a subject that is 15.7 in (40 cm)-infinity from the camera.

Use the Distance Scale function on the camera to display the distance between a subject on the camera's screen. Refer to your camera manual for more details.

► **Camera body:** Camera body (I-Function) to camera body (I-Function) distance

► **Lens:** Camera body (I-Function) to lens (I-Function) distance

► **Operating temperature:** 0~40 °C

► **Operating humidity:** 5~85 %

► **Specifications** may change without notice for better performance.

Health and Safety Information

Please read the following safety tips carefully for proper and safe use.

► **Warning:** Do not stare at the sun through the lens or camera. This may cause severe damage to your eyes.

► **Caution:** Keep your lens or camera away from small children and pets.

► **Setting the Focus Method**

Set the focus method on the camera.

► **Using the full-time manual focus:** If you set auto focus (AF) on the camera, you can adjust the focus more precisely by using both auto focus (AF) and manual focus (MF).

► **Do not apply excessive force to the front of the lens while the camera is in auto focus (AF). Doing so may cause the lens to malfunction.**

Lens Storage and Maintenance

• Store the lens in dry and well-ventilated areas.

• Do not store the lens in areas of high temperature or humidity or in a closet, a car, or confined area where chemicals are stored.

• The lens is not waterproof. Be careful not to allow it to get wet.

• Use only sturdy tripods. Lightweight or unstable tripods may fall over and damage the camera.

Using I-Function

When you press the I-Function button on the lens, you can use the I-Function button on the camera body to change the settings.

In the I-Effect mode, you can select scenes or filter effects that your camera supports. The I-Function ring allows you to zoom in on a subject with less degradation of photo quality than the Digital zoom. This feature is available only when your camera supports I-Scene mode.

► **Using I-Function:** If you set auto focus (AF) and manual focus (MF) on the camera, you can adjust the focus more precisely by using both auto focus (AF) and manual focus (MF).

► **Do not apply excessive force to the front of the lens while the camera is in auto focus (AF). Doing so may cause the lens to malfunction.**

Conservation et maintenance de l'objectif

• Stockez l'objectif dans des endroits secs et bien ventilés.

• Ne rangez pas l'objectif dans des endroits où la température ou l'humidité est extrêmement élevée, et dans un placard, dans un châssis ou dans toute autre zone confinée où des produits chimiques sont stockés.

• L'objectif n'est pas étanche. Veillez à ne pas le mouiller lorsque vous utilisez près d'une source d'eau.

• Ne laissez pas de produits chimiques tels que du diluant, de l'alcool ou du benzène pour nettoyer l'objectif.

• Ne laissez pas tomber l'objectif et ne le soumettez pas à des chocs excessifs. L'objectif est un produit optique précis.

• Évitez d'utiliser l'objectif en cas de changement climatique soudain.

• Utilisez l'objectif dans un sac à plastique ou un étui d'appareil photo pour protéger les particules et protéger la lentille des scratches.

• Ne do not put the camera mounted on a tripod without the lens cap. The inside of the camera can be damaged by direct sunlight.

• Check the lens once every year or for best performance.

• Do not apply excessive force to the front of the lens.

• For safe use of the lens, mount or dismount the lens while the camera is turned off.

• The lens is not waterproof. Be careful not to allow it to get wet.

• Use only sturdy tripods. Lightweight or unstable tripods may fall over and damage the camera.

Using a Lens Hood (See illustration E)

To prevent deterioration of image quality by blocking out unnecessary light, use a lens hood.

► **When you use a flash in situations where the distance between the subject and the camera is close, the flash light may be partially blocked by the lens or a lens hood. To ensure proper lighting, remove the lens hood or adjust the distance between the camera and subjects**

